



Fracture Technology Associates



**Automated Fatigue Crack Growth Testing – G4 Development
Version 3+.15.06
Supplement to Variable Amplitude Manual**

June 2015

Keith Donald
Fracture Technology Associates
2412 Emrick Boulevard
Bethlehem, PA 18020
610-868-3054
www.FractureTech.com

1.0 Supplement to Variable Amplitude Manual


The following are upgrades to the Variable Amplitude (VA) software.

- A custom waveform sequence allows unique time based ramps and holds between specified end levels. Enhanced waveform integration is included to minimize the risk of underload/overload.
- The 'Matrix' has been enhanced to allow activating and changing the waveform sequence according to the event table.

1.2 About This Manual

This document is intended to provide temporary support of upgrades that have not yet been incorporated in FTA's variable amplitude reference manual.

4.1 Splash Screen



When the FCGR testing program is first opened, the **Splash Screen** is displayed. The application title and version number are identified at the top of this form.

From this form the **Crack Monitor** type (**Compliance** and/or **DC Potential Drop**) is selected. If a different crack monitor type is required for subsequent tests, the program must be shut down completely and restarted.

The **Application** is also selected at this point. Options are **Steady State** or **Variable Amplitude**. For the **Custom Waveform Sequence**, the **Steady State** selection must be used.

4.4.1.1 Initialize

Data Input

Test ID:

Force **Compliance** **Storage** **Limits**

Initialize **Calibration** **Coefficients** **Dimensions**

Test ID

Clear Correction

Initialize

Clear Data Buffer

Clear Cycle Count

Clear Elapse Timer

Cycle Count Preset

Restore Data Buffer

Specify Data Buffer Size

Data Buffer

% Used

Data storage path

New screen showing **Clear Correction** check box.

4.4.1.6 Force

Data Input [Test ID: test]

Initialize Calibration Coefficients Dimensions
Force Compliance Storage Limits

Maximum Load (lbs) 2000.0
Stress Ratio (R) 0.00

Load Decrease Only

Control Type
 Constant Load
 K Control - (Constant C)
 K Control - (Look-up Table)

K Control Mode
 Fixed Stress Ratio
 Constant Kmax

K Control Parameters

Initial a (in)	0.00	1.04004
Initial Kmax (ksi sqrt[in])	0.0	29.09
K-Gradient (1/in)	0.00	
Initial Delta K (ksi sqrt[in])	0.0	
<input type="checkbox"/> Enable K-Gradient Calculation		
Final a (in)	0.00	
Final Kmax (ksi sqrt[in])	0.0	

Receive from ADwin Send to ADwin Print to Log

New screen showing **Stress Ratio** is grey out.

4.5 Control

4.5.1 FULL FUNCTION GENERATOR CONTROL (VARIABLE AMPLITUDE)

Full Function Generator Control

DAC Rate: 400. Data Sync: 68,334 Circular Buffer: 68,353

Waveform
 Sine
 Triangle

Response Rate
 5x
 Standard
 1/5

Command Control
 Standard
 1/2
 1/4

Control Status
 FNG Shutdown
 Command Control
 Slope Analysis
 Data Storage

Clear Message **Reset FNG**

Display
 Volts
 Engr.

Raise Rate **Raise Hz(max)** **Raise Hz(min)** **Raise Hold**
 1000 10.0 0.100 0

Lower Rate **Lower Hz(max)** **Lower Hz(min)** **Lower Hold**

Pre Load
 0

Coarse Adjustment
 Fine Adjustment
 Ramp to Hold Level

Load Rate (units/sec)
 1000

Frequency (Hz)
 0.612

Cycle Count
 1,227

Pass Count

IN 2

Run **STOP**

End Point Status		Load (lb)	FNG Out (lb)	Load (lb)	Disp (in)
Error (lb)	3DCF (lb)				
0	0	0	1,017	1,015	0.00406
Max 0	0	202	284	529	0.00212
Min 0	0	1,019	1,019	283	0.00113

No FNG shutdown conditions

New screen showing variable amplitude **FNG**.

4.5.1 FULL FUNCTION GENERATOR CONTROL (CUSTOM WAVEFORM SEQUENCE)

The screenshot displays the 'Full Function Generator Control' software interface. The 'Custom Sequence' mode is selected. The interface is divided into several functional areas:

- Waveform Selection:** Radio buttons for Sine, Triangle, Custom Shape, and Custom Sequence (selected).
- Start-Stop Mode:** Radio buttons for Max, Min, Rising (selected), and Falling.
- Parameter Controls:**
 - DAC Rate: 125
 - Data Sync: 92,655
 - Buffer: 92,942
 - Custom Sequence Index: 3, Segment: 13, Time (sec): .3, Level %: 15.0
 - Buttons: Clear Message, Reset Hold, Reset Max-Min, Raise Freq, Raise Hold, Raise Max, Raise Min, Lower Freq, Lower Hold, Lower Max, Lower Min, Pre Load (0), Preset Max-Min, Cycle Count (187), Frequency (Hz) (0.250), Coarse Adjustment (selected), Fine Adjustment, Ramp to Hold Level (checked), Reset Waveform.
- Control Status:** Checkboxes for FNG Shutdown, Command Control, Slope Analysis, DCPD Analysis, and Data Storage.
- Display Units:** Radio buttons for Volts and Engineering (selected).
- Waveform Graph:** A vertical axis from -100% to 100% showing a sequence of points (red, blue, red, blue).
- Run/Stop Buttons:** A large green 'Run' button and a pink 'STOP' button.
- Target Load and FNG Out Table:**

	Target Load (lb)	FNG Out (lb)	Load (lb)	Disp (in)
	0	700	701	0.00280
Max	2,000	2,001	2,001	0.00800
Min	200	201	216	0.00086
- Status:** 'No FNG shutdown conditions'.

The above display shows features for the **Custom Waveform Sequence** mode.

A **Reset Waveform** button has been added to allow restarting at the beginning of the waveform.

The following features have been added or modified as follows:

- Across the top of the form are useful tracking parameters as follows:
 - DAC Rate – Analog input data acquisition rate in readings per second.
 - Data Sync. – Starting location of data acquisition cycle in 100,000 word circular buffer.
 - Buffer. – Current location of data acquisition cycle in 100,000 word circular buffer.
 - Custom Sequence (waveform)
 - Index # – Current Index
 - Segment # – Current Segment
 - Time (sec) – Elapse time in current segment.
 - Level % – Level in current segment.

- **Reset Max/Min** – Pressing this button resets the maximum and minimum to the **Set Point** value but does not reset the hold value.

- **Reset Hold** – Pressing this button resets the hold value to the **Set Point** value.

- **Waveform: Sine, Triangle, Custom Shape (previously called User Defined) or Custom Sequence** can be selected. The **Custom Shape** mode allows construction of waveforms, such as saw-tooth and trapezoid. The **Custom Sequence** mode provides greater flexibility. The **Custom Shape** or the **Custom Sequence** mode cannot be activated until the corresponding form is selected from the **Control** menu and the corresponding waveform created or loaded (discussed in Section 4.5.3, below). The default mode is **Sine**. It is possible to change the waveform while the function generator is running. It is also possible to automatically change the waveform from the **Matrix** form. The upper right corner of the **FNG** display includes useful status information when the **Custom Sequence** waveform option is selected

- When the **Custom Waveform Sequence** is selected, the targeted **FNG** command signal is output regardless of the status of the **Command Control**. If **Command Control** is enabled, then the **FNG** output is adjusted to compensate for loading errors.

- The **Command Control option** adjusts the aggressiveness of the function generator compensation in response to errors between the target maximum and minimum loads and the actual maximum and minimum loads. When the **Custom Waveform Sequence** is selected, the waveform compensation works differently to account for the relatively slow frequency associated with typical custom waveform sequences. In this mode of operation, waveform compensation is continuous rather than based on historical maximum and minimum response.

Ramp rates and limits as well as integration rates and limits can be set by the user in the **Custom Waveform Sequence Control** form.

4.5.3 WAVEFORM

4.5.3.2 Custom Waveform Sequence

A **Custom Waveform Sequence** form has been added under the **Control** menu for creating user-defined waveforms sequences (.dat files). Custom waveform sequences of up to 1000 data entries may be generated. Multiple waveform sequences may be created, each uniquely defined by the index number. Entries within a unique waveform sequence are defined by the segment number. Waveforms can be created using the form shown below, or in a text editor.

Segment #	Time (seconds)	Level (0 to 100%)
1	0.0	0.00

One display and three text boxes appear at the top of the **Custom Waveform Sequence** form.

- **Index #** is the unique waveform identifier allowing multiple custom waveform sequences to be stored in a single file.
- **Segment #** is associated with each unique waveform sequence. A minimum number of four segments is required for each waveform sequence, even if the sequence can be defined with less than four. The **Segment #** is not user selectable and cannot be reset for each **Index #**.
- **Time (seconds)** is elapsed time to get to the specified level from the previous level. The time associated with Index 1 is zero, which defines the starting point.
- **Level (0 – 100%)** is targeted endpoint in % of upper and lower limits.
- **Active Index** specifies which waveform sequence (Index) is active. This value must always correspond to one of the available indexes in the waveform sequence file.

The following table defines two simple waveform sequences

<u>Index</u>	<u>Segment</u>	<u>Time (sec)</u>	<u>Level (%)</u>
1	1	0.0	0.00
1	2	5.0	100.00
1	3	50.0	100.00
1	4	5.0	0.00
2	5	0.0	0.00
2	6	50.0	100.00
2	7	10.0	0.00
2	8	0.0	0.00

The first waveform sequence (index 1) is a trapezoidal waveform starting at minimum load with a rise time to maximum load in 5 seconds; a hold at maximum load for 50 seconds; followed by a return to minimum load in 5 seconds.

The second waveform sequence (index 2) is a saw-tooth waveform starting at minimum load with a rise time to maximum load in 50 seconds; followed by a return to minimum load in 10 seconds, The fourth segment is a dummy entry since a minimum of four segments are required.

For each waveform sequence, the first segment defines the initial endpoint level. The time for this segment must be zero. The last segment in the sequence must have the same level as the first segment.

NB It is recommended that the number of points for A/D Data Acquisition (Options tab) be set to the maximum of 5000 when using this option (See Section 4.4.2).

4.5.3.3 Custom Waveform Sequence Control

A **Custom Waveform Sequence Control** form has been added under the **Control** menu for establishing ramp rates and limits as well as integration rates and limits when using the **Custom Waveform Sequence** features of the software.

Parameter	Value
Stop Ramp Rate (units/second)	500
Run Ramp Rate Limit (units/second)	5000
Integration Rate 1 (units/second)	2.5
Integration Rate 2 (units/second)	2.5
Integration Limit (units)	100
Integration Value (1)	0.0
Integration Value (2)	0.0

Four text boxes appear in the **Custom Waveform Sequence Control** form.

- **Stop Ramp Rate** – This variable specifies the ramp rate (units/second) to the hold level when the function generator is stopped.
- **Run Ramp Rate Limit** – This variable specifies the maximum ramp rate allowable (units/second) when the function generator is running. If a segment in **Custom Waveform Sequence** file exceeds this rate, the green **Run** button on the function generator turns yellow.
- **Integration Rate** – This variable specifies the integration rate (units/second) for load error compensation while the function generator is running. No integration takes place while the function generator is stopped. For the dual integration mode, two integration rates can be provided.

- **Integration Limit** – This variable specifies the integration limit for load error compensation.
- **Integration Reset** – This button sets the integration value to zero.
- **Integration Mode** – This option selects either a single parameter or dual parameter integration mode. In the dual parameter mode, separate integration terms are used for the minimum and maximum level. In that way, the system can be tuned for a non-linear response between minimum and maximum load.
- **Display Units** – This option chooses between volts and force units.

The default settings for these control parameters are as follows (in volts):

Stop Ramp Rate – 1.0 volts/second
Run Ramp Rate Limit – 10.0 volts/second
Integration Rate – 0.005 volts/second
Integration Limit – 0.2 volts

For overload protection, the instantaneous load is scanned 500 times per second. As overload or underload conditions are approached, the rate of ramp rise or fall is limited to 1 volt/sec within 50 mvolts of limit, 0.2 volts/second within 25 mvolts of limit and 0.02 volts second within 5 mvolts of limit. If the limit is reached prior to reaching the upper and lower level of the waveform (100% or 0%), the waveform rise or fall is momentarily halted, to prevent overload or underload, although integration and command compensation continue.

During transition to or from the **Custom Waveform Sequence** mode to the **Sine**, **Triangle** or **Custom Shape** waveforms, the ramp rate is limited to ~0.3 volts/second until the existing function generator output coincides with the new waveform output.

4.5.4 THE MATRIX

The **Matrix** has been modified to include automatic changing of the waveform (1 = Sine, 2 = Triangle, 3 = Custom Shape, 4 = Custom Sequence). If the **Custom Sequence** option has been selected, then the **Waveform Sequence Index** must also be defined.

See standard manual for more detail on the use of the **Matrix**.


4.6 Display

4.6.1 STATUS: VARIABLE AMPLITUDE

Status - Compliance									
Test ID: <input type="text" value="test"/>									
	Target Load		Command Signal		Actual Load		Clip Gage		
	lb	%	lb	%	lb	%	in	%	
Max	<input type="text" value="283.8"/>	<input type="text" value="5.7"/>	<input type="text" value="447.3"/>	<input type="text" value="8.9"/>	<input type="text" value="938.0"/>	<input type="text" value="18.8"/>	<input type="text" value="0.00375"/>	<input type="text" value="18.8"/>	
Min	<input type="text" value="1101.1"/>	<input type="text" value="22.0"/>	<input type="text" value="1101.0"/>	<input type="text" value="22.0"/>	<input type="text" value="446.6"/>	<input type="text" value="8.9"/>	<input type="text" value="0.00179"/>	<input type="text" value="8.9"/>	
a/W	a	Last a	Next a	Count	Time	Date			
<input type="text" value="0.5201"/>	<input type="text" value="1.04019"/>	<input type="text" value="1.04000"/>	<input type="text" value="1.05000"/>	<input type="text" value="2.421"/>	<input type="text" value="11:49:53"/>	<input type="text" value="3/21/2015"/>			
					<input type="text" value="0.53"/>	<input type="text" value="0.02"/>			
Slope #	Slope#	Corr	Kmax	Delta K	da/dN	Damage			
<input type="text" value="20"/>	<input type="text" value="3"/>	<input type="text" value="1.00000"/>	<input type="text" value="29.10"/>	<input type="text" value="29.10"/>	<input type="text" value="1.970E-7"/>	<input type="text" value="1.0021"/>			
						<input type="text" value="1.0024"/>			
EvB/P	Count	a	EvB/P	Count	a				
<input type="text" value="59.9833"/>	<input type="text" value="2.418"/>	<input type="text" value="1.04019"/>	<input type="text" value="59.9985"/>	<input type="text" value="271"/>	<input type="text" value="1.04030"/>				

New screen showing variable amplitude status.

4.6.3 LOAD – DISPLACEMENT DISPLAY



New screen showing variable amplitude load-displacement display.